


QUICK USER MANUAL

BOX OPENING


Ask someone for help when removing the machine from the box.



1

TURN ON BLUETOOTH AND LOCATION

Turn on your phone's Bluetooth and location (Android users only).



3

BLUETOOTH SETTINGS


You do not need to pair or connect the Staneg device from the Bluetooth settings.



5

DOWNLOAD STANEG APP

Download Staneg app from Play Store(Android) or App Store(Iphone).



2

APP PERMISSIONS


Grant app permissions.
For Android users, you need to set the location property of the Staneg app to allow.



4

PRESS YOUR MACHINE'S POWER KEY

After pressing the power button of your machine, connect to the device named "Staneg" from within the Staneg application.




6

Note: Detailed explanation and visuals are in the Staneg user manual.

WARNINGS

CHARGE BEFORE FIRST USE

Please charge the machine before using it for the first time.



1

KEEP AWAY FROM WATER AND RAIN

Keep the machine away from water and rain. It is not water resistant.



3

PLASTIC BUCKET

Do not use a plastic bucket when transferring your balls to the machine. Use metal or cardboard containers.



5

DO NOT START THE MACHINE WHEN CHARGING

Do not operate the machine while charging. The power key should be in the 0 (off) position.



2

BALL ESCAPEING INTO THE MACHINE

If a ball gets into the machine during your shots, please stop the machine immediately and take the ball out of it.



4

BALL JAM

In case of a ball jam, remove the balls stuck in the launch wheels and restart the machine.



6

Note: Detailed explanation and visuals are in the Staneg user manual.