



TENNIS BALL MACHINE
USER MANUAL

TABLE OF CONTENTS

Security Warnings.....	3
Recognize Machine Parts.....	5
Storage.....	7
Maintenance.....	7
Transportation.....	7
Before First Use.....	8
Battery and Charging.....	9
Remote Control.....	10
Usage.....	10
Phone Program and Interface Introduction.....	13
Training and Throwing Details.....	14
Support.....	17
Warranty.....	17
Warranty Administration.....	17
Conditions of Warranty	19

SECURITY WARNINGS

This tennis ball machine is designed and tested to ensure safe play, provided that it is used in accordance with the following safety warnings. Failure to follow below instructions may result in serious personal injury or property damage.



Stay away from the front of the machine where the ball is out.

Keep children away from the machine while the machine is running.

Keep people with physical and mental disabilities away from the machine while the machine is running.



Do not put your hand or foreign objects in front of the machine.

If the ball gets stuck and gets into it, power off the machine and take the ball after the wheels stop.



Never touch the spinning wheels.

Do not put your hand in the rotating part of the ball hopper, do not try to place the balls.

Do not intervene when working on the rotating part in the ball hopper.

Do not put new ball while the machine is running and the rotating part in the ball hopper.



The machine should not be ran in wet conditions and rain.

Keep away from water.

Store the machine in a dry environment.

Never run the machine while the machine is charging.

The machine is 18 kg. Carefully lift the machine.



Use correct removal methods .

Keep your machine clean.


**Turn off your machine in an emergency.
The lower right button on the back cuts the power completely.**

**Use a tennis ball in your machine. Do not use cricket ball.
Cricket ball will damage your machine.**




The recommended ball is a training (non-pressure) ball. Our machine is suitable for both orange (stage 2) and green (stage 3) low pressure balls.

Red (Stage 1) balls of large sizes cannot work.



POWER SWITCH



CHARGING SOCKET

STORAGE

We recommend storing your machine in a confined space, preferably with the lid closed for protection. Do not expose your machine to rain, even with the cover protection, as rain can damage your machine. Do not expose your machine to direct sunlight and hold on rubber feet. Do not position sideways or opposite.

MAINTENANCE

At the end of 3-4 workouts, when the machine is off, remove the dust and ball fluff inside the mouth with the help of a vacuum machine. The outside of the machine can be wiped with a soft damp cloth, but please make sure that no water gets inside the machine.

TRANSPORTATION

To move the machine, slide out the handle on the front of the machine (bottom). Lift the machine by the handle until it sits on the rear wheels. Simply pull the machine to your target. Never move the machine while it is powered on. Please keep the machine upright at all times. Placing it on its side may cause damage and void your warranty. Do not store the machine in your car when the temperature exceeds 30 degrees.

BEFORE FIRST USE

BOX OPENING

Thank you for purchasing the Staneg *Tennis Ball Machine*.

Please read the entire user manual.

When moving, carry it upright.

Take the charger out of the box first.

While removing the machine from the box, hold it by the bottom plate.

Check the machine for damage that may occur during transportation.

Parts out of the box:

- Machine
- Machine's hopper
- Charger
- Remote control
- User manual and warranty document

After removing all the parts, turn the hopper over and place it on the machine. You can start the machine by pressing

the power button on the bottom right of the machine. In the future, you may need to return your machine to its supplier, so we recommend keeping the box.

BATTERY AND CHARGING

ATTENTION! NEVER PRESS THE POWER BUTTON WHEN THE MACHINE IS CHARGING!

ATTENTION! THE CHARGER IS NOT TO RUN THE MACHINE. MACHINE WORKS WITH THE BATTERY INSIDE!

The charging of your machine should last between 3-8 hours depending on the settings you use. Follow the battery information from the indicator on the top left of the phone program. Do not use and charge when the indicator drops below 10%.

Charging the machine once a month, even if you are not using the machine, ensures a long life of the battery.

CHARGING THE BATTERY

Plug the charger into the socket first. Green light (full) will come on.

Plug the other triangle-like end of the charger into the socket on the bottom left of your machine.

Orange (charge) light will be on.

The green light will be on when the battery is full.

When the green light is on, please unplug the machine and then the charger.

Filling process is expected to take 3-5 hours.



You can start and stop training with the remote control. If it is your first workout after starting the machine, you should send the training information from the phone program.

Due to the small remote control, it does not disturb you while playing games.




USAGE

The machine can be placed right behind the place called the center mark on the court, but different trainings can be created by placing them elsewhere. Please add the balls

to the hopper before starting. Do not add balls while the mixer is rotating, otherwise it may cause ball jam. **The maximum capacity is 150 balls (we suggest you put less than 100 balls).**

Please do not overfill the hopper as excess weight can damage the feed motor.



1. Download the Staneg app from the Play Store (Android) or App Store (Iphone) apps. It's free.

2. Press the power button of your machine. You will see the orange led light up.

3. Turn on your phone's bluetooth function and log into the Staneg app.

4. Please allow for location function.


5. If the devices are not visible at the bottom, turn on your location feature.

6. Connect to Staneg.

7. Choose one of 9 programs.

8. Select speed, spin, ball frequency and vertical axis settings.

9. If you have chosen one of the vertical oscillation, lobe or manual programs, select the horizontal axis setting.




10. Press the start button in the upper right. The settings you selected have been sent to the device.

11. Press the start button again to start.

- Speed: Allows the ball to be launched faster or slower.
- Spin: Allows the ball to be launched as +1 and +2 topspins, -1 and -2 backspins.
- Ball Frequency: Sets the ball's firing frequency 2-10 seconds.
- Vertical: Changes the vertical angle. By increasing the setting, the ball can be raised higher.
- Horizontal: Changes the horizontal angle. This setting is active in "Vertical Oscillation", "Lob" and "Manual" programs.

PHONE PROGRAM AND INTERFACE INTRODUCTION



The upper left indicator shows the percentage of your machine's battery.

The "hand" or "play" symbol in the upper right part allows you to start and stop training.

5 training programs allow you to keep features such as "speed", "spin", "ball frequency", "vertical" and "horizontal".

9 green symbols represent 9 different training modes.


10 different orange gray symbols in turn determine the speed, spin-slice, frequency, vertical and

horizontal characteristics of the ball in training.



The bottom is where the Bluetooth devices scanned and found are listed.

In the bottom panel, there is a brief use of the program in the "About" section and useful links and contact information in the "Media" section.

TRAINING AND THROWING DETAILS




Horizontal Oscillation: It throws balls on the court in the form of horizontal oscillation. When a row ends, it continues from where it throws the first ball. Thus, 5 balls allow you to dribbling to the other side at the end. If you want to shoot faster during training, simply tap the top button on the "Speed" tab. If it shoots out of the court due to your speed increase, please click the lower "Vertical" buttons to make the ball come lower so your ball will fall into the court.



Horizontal Random: Horizontal oscillation is a mixed version of the training program. It allows you to practice attention and reflexes by throwing the ball differently from the next one. "Speed" and "Vertical" adjustment is valid as in horizontal oscillation.

Horizontal - Vertical: It is a program that oscillates both horizontally and vertically. After the first ball arrives, the second ball comes forward on the vertical axis. The third ball moves on the vertical and horizontal axis. When 10 balls are finished, it returns to the beginning from the position where the first ball came from. If your balls correspond to the net during the training, press the top button of the "Vertical"

adjustment keys. If your balls go out of the court, press the lower button of the “Vertical” adjustment keys.



Forehand-Backhand (two drills narrow):

This program allows you to perform forehand and backhand strokes in turn, throwing the ball to the right and left of the midline. But it keeps you in a narrow range.


It allows you to train without jogging. The speed and vertical settings are the same as in previous programs.



Forehand-Backhand (two drills medium):

This program allows you to perform forehand and backhand strokes in turn, by throwing the ball to the right and left of the midline. It keeps you in a range that will

take a few steps. The speed and vertical settings are the same as in previous programs.



Forehand-Backhand (two drills wide):

This program allows you to perform forehand and backhand strokes in turn, throwing the ball to the right and left of the midline. But it keeps you in a wide range. You need to do

your strokes by jogging. The speed and vertical settings are the same as in previous programs.



Vertical Oscillation: It shoots on the court in the form of a vertical oscillation. Throws the ball between the baseline and the service line. You need to hit the ball by jogging forward and backward. If your balls correspond to the net during the training, press the top button of the “Vertical” adjustment keys. If your balls go out of the court, press the lower button on the “Vertical” adjustment keys. You can make vertical oscillations in different parts of the court from the “Horizontal” adjustment keys.



Lob: It allows you to practice Smash in the Lob program. You can shoot different areas with the “Horizontal” setting button. You can make your settings with the Vertical and Speed button.



Manual: You can throw your balls anywhere on the court by using the Horizontal and Vertical adjustment keys. You can produce different shots by placing your machine in different places. You can save all of these programs.

SUPPORT

When calling for support, please tell us the serial number on the bottom of your machine. Also, any video shooting to show the problem will greatly assist us in solving your problem. If you hear any unusual sounds, please report them and where the sound came from.

WARRANTY

Should any part fail due to defective workmanship or faulty materials within the warranty period, Staneg or its distributor will repair or, (at distributor's option), replace the defective part free of charge. The warranty period is country specific, please contact the Staneg distributor in your country or the place of purchase for details.

WARRANTY ADMINISTRATION

Warranty is administered by your country's authorized Staneg distributor. Please visit our website www.staneg.com for the contact details of your country's Staneg distributor. To ensure speedy processing of your warranty service claim, ensure that you inform us of all specific details about your machine including the serial number & model as well as a detailed description of the fault. Any videos you can provide us are considered very helpful.

Exposure of the ball machine to the elements should be minimized. Upon completion of play, please store the machine under cover. Damage caused to your machine from

being exposed to the elements is not covered under warranty.

This warranty does not cover the purchaser or any other person for damage, malfunction or loss due to the following:

- Lack of maintenance, abuse, neglect, misuse, accident or improper usage of this appliance.
- Scratches, dents, corrosion or general wear & tear on the machine.
- Exposure to the elements, insects, weather or hail.
- Unauthorized repairs during the warranty period.
- Acts of God.
- Use on power voltages other than that specified for your machine.

Servicing of this nature is chargeable.

Staneg or its authorized distributors under no circumstances can be held liable to the Customer or any person for any natural event or consequential damage, including but not limited to personal injury or property damage.

CONDITIONS OF WARRANTY

- The machine is to be delivered to the Staneg distributor's service department or authorized service agent and freight charges both ways are paid by the owner. No liability is accepted for loss or damage during transit.
- The machine must always be operated and maintained in accordance with the instructions supplied.
- No alterations or repairs have been carried out without obtaining the distributors prior consent. Such repair or any replacement does not extend the warranty period.
- Proof of purchase must be provided to verify purchase date and establish the warranty period. Only the original purchaser is covered under this warranty.
- The warranty period is calculated from the date of purchase only.
- Where this warranty is inconsistent with any state laws, the statutory rights of the purchaser shall prevail.
- Parts installed from other manufacturers' products will void this warranty.

